1800 330 118



## **POSITIONING AIDS**



POSITIONING SET OF MIXED FOAMS (SET 1)

Foam wedges and plocks are a key component to creating high-quality radiographs.

• 2x FOAM0 2-Circle:

100x50 mm • 2x FOAM0 3-mall Wedge 210x75 x75mm • 2x

210x75 x75mm 2x FOAM0 4-15° Wedge

250x25 0x50m m 2x FOAM0 5 - 90° Wedge

250x18 0x180m 2x FOAM0 7-Thin Block: 252x20

FOAM1 8-Block:

200x10



POSITIONING SET OF MIXED FOAMS (SET 2)

SET OF MIXED FOAMS

Variety of shapes and sizes available, or design your own.

- 2x FOAM0 2 Circle
- 2x FOAM0 3 -Small Wedge • 2x FOAM0 4 - 15° Wedge
- FOAMO FOAMO Wedge FOAMO Long 9 Wedge FOAMO 7-in Block

CODE C-FOAM11-2

1800 330 118



0x100m m CODE C-FOAM11-1

1800 330 118

