

## MARKERS



### **BEEKLEY S-SPOT® 607 FLORALS®**

### **S-SPOT® CT Simulation Marker 607 Florals®**

Help define architectural distortion at the biopsy site by delineating the exact location of incision.

**Ref: 607, (QTY: 363cm cut to measure roll/box)**

- 33mm diameter radiopaque line
- burnout-resistant brighter image
- for marking scars and field borders

**CODE C-BEEK607**

